

DATA SHEET

REF. HANDRY-W, HANDRY-C

HAND DRYER HIGH SPEED



GENERAL

WARRANTY: 2 years.
LIFECYCLE OF MOTOR: 5 years (based on average usage: 200 time per day).
ACTUATION METHOD: It activates when detecting hands by an infrared led.
LENGTH OF WIRE: 1800mm.

AMBIENCE



TEMPERATURE RANGE: 5 / 45°C.
HUMIDITY RANGE: 20-90%.

HAND DRYER HIGH SPEED

MOUNTING: Screw to the wall.
NET WEIGHT: 4,4Kg.
GROSS WEIGHT: 5,2Kg.
DIMENSIONS: 250 x 168 x 468mm / 9,84 x 6,61 x 18,42inch.
MATERIAL: ABS plastic and Polypropylene.
COLOR: White.
MARKETING: Can be customized with logo.

ELECTRONICS

POWER SOURCE: 220V-50Hz / 110V.
POWER: 1900W.
WORKING CURRENT: 4,54A.



PACKING ATTACHMENT

Chart	Function	Amount
	Iron bracket use for hanging the hand dryer	1
	Screws 3.8* 30mm to fix the iron bracket and 1 for the hand dryer	5
	Plugs 8* 35mm	5
	User manual	1

HOW TO USE

1. Plug in the appliance. To dry your hands, place them under the sensor, rub them together, and slowly move both the palms and the backs of your hands. It features a hot / cold air system depending on the ambient temperature: Ambient Temp. -22°C: Hot air / Ambient Temp. +22°C: Cold air. Remove your hands from the dryer to stop it.

Note: After 30 seconds of continuous use, the hand dryer will automatically stop thanks to its safety device. However, if you remove your hands and place them back under the unit, the hand dryer will start operating again.

DIALY USE & MAINTENANCE


HOW TO DISASSEMBLE AND CLEAN WATER COLLECTION BASE

Disassemble water collection base from main frame: press the fastener of main frame and pull the sink to your site then you can disassemble. Pour away the water. Clean the water collection. Wash the dirt off by water. If there is much dirt, please use a soft rag to clean that. Put the water collection base into main frame and make sure it is tight.

CLEAN THE VENTILATION AND SILENCE SPONGE (ONE OR TWO TIMES A MONTH)

Please clean the ventilation net and silence sponge regularly, unplug the hand dryer before take off the ventilation net and silence sponge. Take off the ventilation net and silence sponge from the machine. Clean the ventilation net and silence sponge with vacuum cleaner. Do not clean the ventilation net and silence sponge with water or steel brush, after some time of use, the ventilation net and silence sponge will become brown, it does not affect its functions. Install the ventilation net and silence sponge back to the machine.

Note: Clean this machine with wet cloth (with slight detergent is recommended). Always keep the sensor cover clean. Please do not use any chemical diluents, detergents, benzene, sterilizing agent or steel brush to clean this machine.



HAND DRYER ON PALLETS

Register No.: AN-04-DM-01
Version: 002
Date: 11 / 10 / 2021